




## CHEMICAL FREE, INLINE CAP & MOIL OR BOTTLE NECK STERILIZATION

# **CLARANOR PULS'COMBI HDPE®**

### 1 ELECTRONIC BAY + 1 CAP STERILIZER + 1 MOIL STERILIZER





CAP, surface in contact with the product

- Compact & easy to integrate
- Chemical free & dry sterilization
- Instant treatment

### ESL 60-90 DAYS



FULL CAP, both sides of the cap

- No warm up or preparation time
- No residue



## **CLARANOR PULS'COMBI HDPE®**

### CHEMICAL FREE, INLINE CAP & MOIL OR BOTTLE NECK STERILIZATION

## Pasteurized, flavoured, organic and non dairy milk, RTD coffee, drinking yogurt, milkshake ...


#### MOIL/ BOTTLE NECK



- The optical cabinet is integrated on the bottle infeed conveyor. The optical cavity is built in a «tunnel-cabinet» that provides light shielding.
- Moils or bottle necks are accurately flashed while movingthrough the optical cavity before filling.

#### PERFORMANCE:

4 log red on Aspergillus brasiliensis




• The optical cabinet is integrated above the capper, designed with 1 reflector

#### **PERFORMANCE:**

Sterilization of the Internal side of the cap, surface in contact with the product

#### from 3 to 5 log red on bacteria and molds

#### FULL CAP DESIGNED TO ADRESS CROSS CONTAMINATION ISSUES



• The optical cabinet is integrated above the capper, designed with 2 reflectors

#### PERFORMANCE:

Sterilization of both sides of the cap

from 3 to 5 log red on bacteria and molds

#### www.claranor.com







POWERFUI

More info : sales@claranor.com Tel. : + 33 486 408 460